

SELECTIONS

SEL	BRAND	VEHICLE NAME
01	No Can	No Can
02	FORD *NO ALARM	*Transit ('06->'14)
03	ISUZU *NO ALARM	*D-Max ('16->)
04	MITSUBISHI *NO ALARM	*Fuso Canter ('17->)
05	McLaren	570s ('15->)
06	CHANGAN	CS55 ('17->)
08	TESLA	Model S ('12->'15)
09	PORSCHE	Cayman (987) ('05->'12)
	PORSCHE	911 (997) ('06->'11)
	PORSCHE	Boxster (987) ('08->'11)
0A	PORSCHE	718 Cayman (982) ('16->)
	PORSCHE	718 Boxster (982) ('16->)
0B	MG	ZS EV ('18->)
		HS ('18->)
0C	RENAULT	Clio ('19->)
	RENAULT	Captur ('20->)
	RENAULT	Espace ('20->)
	RENAULT	Megane IV ('20->)
	RENAULT	Arkana ('21->)
	RENAULT	Kangoo ('21->)
	RENAULT	Zoe ('19->)
	NISSAN	Juke ('19->)
0F	FORD	Fiesta (Base vs.) ('13->'17)
	FORD	Transit Courier ('14->)
	FORD	Tourneo Courier ('14->)
	FORD	Ecosport ('17->'18)
10	Old Porsche Cayenne ('06 ->'10)	
	Removed from list 36	
11	FORD	Focus C-Max ('03->'10)
	FORD	Focus ('05->'11)
	FORD	Kuga ('08->'12)
12	FORD	Fiesta ('06->'08)
	FORD	Fusion ('06->'12)
13	FORD	Fiesta ('08->'13)
	FORD	Fiesta ('13->'17)

LIGHTS							GEAR	IGNITION			BRAKES		
PARKING	LOW BEAM	HIGH BEAM	REAR FOG	HAZARD	INDICTORS LEFT	INDICATORS RIGHT	REVERSE GEAR	IGNITION ON	ACC REAL	ACC NOT REAL	FOOT BRAKE	PARKING BRAKE	DOOR FRONT LEFT
NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
♦	-	-	-	♦	-	-	♦♦	♦	-	♦	-	-	♦
-	-	-	-	-	-	-	♦	♦	-	♦	♦	-	-
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	-	-	-	-	♦	♦	♦	-	-	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	-	♦
♦	-	-	-	-	-	-	♦	♦	-	-	-	-	-
♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	-	♦
♦	♦	♦	♦	♦	♦	♦	-	♦	♦	♦	♦	-	♦
♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	-	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	-	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
-	♦	♦	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	♦	♦	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
-	♦	♦	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
♦	-	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	-	♦	-	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦

1F Old BMW X3 ('04->'10)

Removed from list 31

20	BMW	Ser 1_KL ('04->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	BMW	Ser 3_KL ('04->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	BMW	Ser 5_KL ('03->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	BMW	X5_KL ('07->'14)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	BMW	X1_KL ('10->'15)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	BMW	X6_KL ('08->)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	MINI	Mini_KL ('07->'13)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	MINI	Mini-Countryman_KL ('10->'17)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦

21	FIAT	Ducato ('06->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	PEUGEOT	Boxer ('06->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	CITROEN	Jumper ('06->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	IVECO	Daily ('06->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦

22 Old Fiat/Lancia models

Removed from list 31

22	FIAT	Ducato ('21->)	-	♦	♦	-	♦	♦	♦	♦	♦	-	♦	♦	♦	♦
----	------	----------------	---	---	---	---	---	---	---	---	---	---	---	---	---	---

23	LANCIA	Musa ('04->'07)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	LANCIA	Musa ('07->'12)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	LANCIA	Ypsilon ('03->'06)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	LANCIA	Ypsilon ('06->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	LANCIA	Delta ('08->'14)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Idea ('03->'08)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Idea ('08->'12)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Panda ('03->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Croma ('05->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Bravo ('07->'14)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Stilo ('01->'05)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Stilo ('06->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FIAT	Linea ('07->'18)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	ALFA ROMEO	159 ('05->'11)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	ALFA ROMEO	Brera ('06->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	ALFA ROMEO	Spider ('06->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	ALFA ROMEO *NO ALARM	*147 ('07->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FERRARI	612 ('04->'10)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦
	FERRARI	F12 Berlinetta ('12->'16)	♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦

24	TOYOTA	Rav 4 ('06->'13)	♦	♦	♦	♦	-	-	-	?	♦	-	♦	♦	♦	♦
	TOYOTA	Rav 4 ('13->'18)	♦	♦	♦	♦	-	-	-	♦♦	♦	-	♦	♦	♦	♦
	TOYOTA	Rav 4 ('18->)	♦	♦	♦	♦	-	-	-	♦♦	♦	-	♦	♦	♦	♦
	TOYOTA	Auris ('07->'12)	?	?	?	?	-	-	-	?	♦	-	♦	♦	♦	♦
	TOYOTA	Auris ('12->'18)	♦	♦	♦	♦	-	-	-	♦♦	♦	-	♦	♦	♦	♦
	TOYOTA	Corolla ('06->'13)	?	?	?	?	-	-	-	♦	♦	-	♦	♦	♦	♦
	TOYOTA	Corolla ('13->'19)	♦	♦	♦	♦	-	-	-	♦♦	♦	-	♦	♦	♦	♦
	TOYOTA	Corolla ('19->)	♦	♦	♦	♦	-	-	-	♦♦	♦	-	♦	♦	♦	♦
	TOYOTA	Land Cruiser ('08->)	♦	♦	♦	♦	-	-	-	♦	♦	-	♦	♦	♦	♦
	TOYOTA	Avensis ('09->'18)	?	?	?	?	-	-	-	?	♦	-	♦	♦	♦	♦
	TOYOTA	iQ ('09->'15)	?	?	?	?	-	-	-	?	♦	-	♦	♦	♦	♦
	TOYOTA	Urban Cruiser ('09->'16)	?	?	?	?	-	-	-	?	♦	-	♦	♦	♦	♦
	TOYOTA	Prius ('09->'16)	?	?	?	?	-	-	-	?	♦	-	♦	♦	♦	♦

	VOLKSWAGEN	ID.4 ('20->)
	SKODA	Enyaq iV ('20->)
80	Old Mazda models	
	Removed from list 36	
81	MAZDA	2 ('06->'14)
	MAZDA	3 ('09->'13)
	MAZDA	Axela ('09->'13)
82	Old Mazda models	
	Removed from list 36	
83	MAZDA	CX-5 ('12->'17)
	MAZDA	3 ('13->'19)
	MAZDA	6 ('13->)
	MAZDA	2 ('14->)
	MAZDA	CX-5 ('17->)
	MAZDA	CX-3 ('16->)
84	FIAT	124 Spider ('16->)
	MAZDA	MX-5 ('16->)
85	MAZDA	3 ('19->)
87	Old Subaru models	
	Removed from list 36	
88	Old Subaru models	
	Removed from list 36	
89	SUBARU	Forester IK (13->)
	SUBARU	Levorg IK (14->)
	SUBARU *NO ALARM	*Forester noIK (13->)
8A	SAAB	9.3 ('03->'12)
8B	SUBARU	Outback IK (14->)
8C	SUBARU	XV IK (18->)
	SUBARU	IMPREZA (18->)
90	VOLVO	V50 ('06->'12)
	VOLVO	C30 ('08->'14)
	VOLVO	S40 ('06->'12)
	VOLVO	C70 ('06->'13)
91	VOLVO	XC90 ('06->'15)
	VOLVO	S60 ('06->'10)
	VOLVO	V70 ('05->'08)
92	VOLVO	S80 ('07->'16)
	VOLVO	XC60 ('08->'12)
	VOLVO	XC70 ('08->'16)
	VOLVO	V70 ('08->'16)

♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦	♦
♦	-	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	-	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	-	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
-	-	-	-	♦	-	-	-	♦	-	♦	♦	-	♦	♦
-	-	-	-	♦	-	-	-	♦	-	♦	♦	-	♦	♦
-	-	-	-	♦	-	-	-	♦	-	♦	♦	-	♦	♦
-	-	-	-	♦	-	-	-	♦	-	♦	♦	-	♦	♦
-	-	-	-	♦	♦	♦	♦	♦	-	♦	♦	-	♦	♦
♦	♦	♦	-	-	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	-	-	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	-	-	-	-	♦	♦	-	♦	♦	♦	♦	♦
-	-	-	-	-	-	-	♦	♦	-	♦	♦	♦	♦	♦
-	-	-	-	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
-	-	-	-	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
-	-	-	-	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦
♦	♦	♦	♦	♦	-	-	♦	♦	-	♦	♦	♦	♦	♦


	TOYOTA	ProAce Verso ('16->)
C3	CITROEN	C4-sir ('10->'18)
	CITROEN	Elysée-sir ('13->)
	CITROEN	C4 Picasso-sir ('12->)
	CITROEN	C4 Cactus-sir ('14->)
	CITROEN	Jumpy-sir ('16->)
	CITROEN	Spece Tourer-sir ('16->)
	CITROEN	C3-sir ('17->)
	DS	DS4-sir ('11->'18)
	DS	DS5-sir ('11->'18)
	PEUGEOT	208-sir ('12->'19)
	PEUGEOT	2008-sir ('13->'19)
	PEUGEOT	301-sir ('13->)
	PEUGEOT	Expert-sir ('16->)
	PEUGEOT	Traveller-sir ('16->)
	OPEL	Crossland X ('17->)
	TOYOTA	ProAce-sir ('16->)
TOYOTA	ProAce Verso-sir ('16->)	
C4	PEUGEOT	3008 ('16->)
	PEUGEOT	5008 ('17->)
	CITROEN	C3 Aircross ('17->)
	CITROEN	C5 Aircross ('17->)
	DS	DS7 Crossback ('18->)
	OPEL	Grandland X ('17->)
C5	PEUGEOT	Partner_IK ('18->)
	PEUGEOT	Rifter_IK ('18->)
	PEUGEOT	208 ('19->)
	PEUGEOT	2008 ('19->)
	CITROEN	Berlingo_IK ('18->)
	CITROEN	Berlingo Van_IK ('18->)
	CITROEN	C5 Aircross_IK ('17->)
	OPEL	Combo Cargo_IK ('18->)
	OPEL	Combo Van_IK ('18->)
	OPEL	Corsa_IK F ('19->)
	OPEL	Mokka ('20->)
OPEL	Mokka-e ('20->)	
C6	OPEL	Corsa F ('19->)
C7	CITROEN	C3_IK ('17->)
CA	MITSUBISHI	Outlander ('12->)
	MITSUBISHI	Eclipse Cross ('17->)
CB	MITSUBISHI *NO ALARM	*Pajero ('08->)
CC	MITSUBISHI	L200_Ik ('15->)
	FIAT	Fullback_Ik ('15->'19)
CD	MITSUBISHI	L200_nolk ('15->)
	FIAT	Fullback_nolk ('15->'19)
CF	TOYOTA	Hilux ('15->)


-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	-	-	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
-	♦	♦	-	-	-	-	♦	♦	-	♦	-	-	-
♦	♦	♦	♦	-	-	-	♦	♦	-	♦	♦	♦	♦



	ALFA ROMEO	Giulia ('16->)
	ALFA ROMEO	Stelvio ('17->)
ED	JEEP	Cherokee ('14->)
F0	OPEL *NO ALARM	*Vivaro A ('06->'14)
	RENAULT *NO ALARM	*Trafic II ('03->'13)
	NISSAN *NO ALARM	*Primastar ('03->'14)
F7	OPEL	Mokka ('14->'16)
	OPEL	Astra J ('14->'15)
	OPEL	Insignia ('14->'17)
	OPEL	Meriva ('14->'18)
	OPEL	Corsa E ('14->'19)
	OPEL	Karl ('15->'19)
	OPEL	Adam ('16->'20)
	OPEL	Mokka X ('17->'20)
	CHEVROLET	Tracker ('14->'17)
	CXHEVROLET	Malibu ('12->)
F8	OPEL	Insignia TSP ('14->'17)
F9	OPEL	Astra K ('15->'17)
	OPEL	Mokka X IK ('17->'20)
	CHEVROLET	Cruze ('16->)
	CHEVROLET	Tracker ('17->)
	OPEL	Karl ('19->)
FA	CHEVROLET	Equinox ('18->)
	CHEVROLET	Traverse ('18->)
	OPEL	Insignia ('17->)
	OPEL	Astra K ('17->)
FB	CHEVROLET	Captiva ('19->)
FC	CHEVROLET	Onix ('19->)


-	◆	◆	-	◆	◆	◆	◆	◆	-	◆	◆	◆	◆
-	◆	◆	-	◆	◆	◆	◆	◆	-	◆	◆	◆	◆
-	-	-	-	◆	◆	◆	◆	◆	-	◆	◆	◆	◆
-	-	-	-	-	-	-	◆	◆	-	-	◆	◆	-
-	-	-	-	-	-	-	◆	◆	-	-	◆	◆	-
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
◆	◆	◆	◆	◆	-	-	◆	◆	-	◆	◆	◆	◆
-	-	-	-	◆	◆	◆	-	◆	◆	◆	◆	◆	◆
-	-	-	-	◆	◆	◆	-	◆	◆	◆	◆	◆	◆


NA = Vehicle analyzed misses the function
- = Vehicle analyzed has the function but no CAN data
◆ = Function exist an is readabe
? = Can data not analyzed























◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
											On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	NA	◆ (saw as Trunk)	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	NA	◆ (saw as Trunk)	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	NA	◆ (saw as Trunk)	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	NA	◆ (saw as Trunk)	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request	
◆	◆	◆	◆	NA	◆	◆	◆	-	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search	
◆	◆	◆	◆ **	NA	◆	-	-	◆	◆	◆	On Request	* Automatic trasmission only ----- ** Trunk saw as trigger OEM alarm
◆	◆	◆	◆ **	NA	◆	-	-	◆	◆	◆	On Request	* Automatic trasmission only ----- ** Trunk saw as trigger OEM alarm

◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	NA	?	?	On Request
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request
◆	◆	◆	◆	◆	◆	-	-	NA	◆	◆	On Request
◆	◆	◆	NA	NA	-	-	-	NA	?	?	On Request
◆	◆	◆	◆	NA	-	-	-	NA	?	◆	On Request
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	To search
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	NA	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	NA	?	?	On Request
◆	◆	◆	◆	NA	-	-	-	NA	?	?	On Request
◆	◆	◆	◆	NA	-	-	-	NA	?	?	On Request

◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	-	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	?	?	On Request
◆	◆	◆	◆	◆	◆	-	-	-	◆	◆	On Request
◆	◆	◆	◆	◆	◆	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	?	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request
◆	◆	◆	◆	◆	◆	-	-	-	◆	◆	On Request
◆	◆	◆	◆	◆	◆	-	-	-	◆	◆	On Request
◆	◆	◆	◆	NA	NA	-	-	-	◆	◆	On Request

* Connection to Engine Can-Bus

◆	◆	◆	◆	◆	-	◆	◆	-	◆	◆	To search
◆	◆	◆	◆	◆	-	◆	◆	-	◆	◆	To search
◆	◆	◆	◆	◆	◆	◆	◆	-	◆	◆	To search

◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search
◆	◆	◆	◆	NA	?	—	—	NA	◆	◆	On Request
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	On Request
◆	◆	◆	◆	NA	?	—	—	NA	◆	◆	On Request
◆	◆	◆	◆	NA	?	—	—	—	◆	◆	To search
◆	◆	◆	◆	NA	?	—	—	—	◆	◆	To search
◆	◆	◆	◆	NA	?	—	—	NA	◆	◆	On Request
◆	◆	◆	◆	NA	?	—	—	NA	◆	◆	To search
◆	◆	◆	◆	NA	?	—	—	NA	◆	◆	To search

◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	On Request

◆	◆	◆	◆	NA	?	—	—	◆	◆	◆	To search
---	---	---	---	----	---	---	---	---	---	---	-----------

◆	◆	◆	NA	NA	◆	—	—	—	—	◆	To search
◆	◆	◆	NA	NA	◆	—	—	—	—	◆	To search

◆	◆	◆	◆	NA	◆	—	—	—	◆	◆	To search
---	---	---	---	----	---	---	---	---	---	---	-----------

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search	* Parking brake is valid only when engine is running
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search	* Parking brake is valid only when engine is running
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search	* Parking brake is valid only when engine is running
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search	* Parking brake is valid only when engine is running
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search	* Parking brake is valid only when engine is running
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	◆	—	—	◆	—	—	To search
---	---	---	---	----	---	---	---	---	---	---	-----------

-	-	-	-	-	-	-	-	-	-	◆	◆	To search	* Connection to Engine Can-Bus
-	-	-	-	-	-	-	-	-	-	◆	◆	To search	* Connection to Engine Can-Bus
-	-	-	-	-	-	-	-	-	-	◆	◆	To search	* Connection to Engine Can-Bus
-	-	-	-	-	-	-	-	-	-	◆	◆	To search	* Connection to Engine Can-Bus
-	-	-	-	-	-	-	-	-	-	◆	◆	To search	* Connection to Engine Can-Bus

◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	

◆	-	-	◆	NA	—	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	NA	◆	◆	To search	


◆	◆	◆	◆	◆	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	


◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
---	---	---	---	----	---	---	---	---	---	---	-----------	--

◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	


◆	-	-	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	
◆	◆	◆	◆	NA	◆	—	—	NA	◆	◆	To search	


◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	
◆	◆	◆	◆	NA	—	—	—	—	◆	◆	To search	






















LOCK VEHICLE		LOCK REPEATED		UNLOCK VEHICLE		AUTO LOCKING		RKE/TSP UNLOCK TRUNK
RKE	TSP	RKE	TSP	RKE	TSP	VEHICLE PRESENCE	CAN DATA	
NA	NA	NA	NA	NA	NA	NA	NA	NA
-	NA	NA	NA	-	NA	-	NA	NA
-	NA	NA	NA	-	NA	-	NA	NA
-	-	-	-	-	-	-	-	-
♦	-	♦	-	♦	-	-	-	** (Trunk unlock)
♦	♦	♦	-	♦	♦	-	-	** (Trunk unlock)
-	-	-	-	-	-	-	-	-
♦	NA	♦	NA	♦	NA	♦	♦	** (Vehicle unlock – Alarm disarms) *
♦	NA	♦	NA	♦	NA	♦	♦	** (Vehicle unlock – Alarm disarms) *
♦	NA	♦	NA	♦	NA	♦	♦	** (Vehicle unlock – Alarm disarms) *
♦	?	♦	?	♦	?	♦	♦	* ** (Hood and Trunk open)
♦	?	♦	?	♦	?	♦	♦	* ** (Hood and Trunk open)
♦	♦	-	-	♦	♦	♦	♦	*Alarm disarms
♦	♦	-	-	♦	♦	♦	♦	*Alarm disarms
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	♦	♦	-	♦	♦	♦	♦	** (Vehicle unlock – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	NA
♦	♦	♦	NA	♦	♦	♦	♦	** (Trunk unlock)
♦	♦	♦	NA	♦	♦	♦	♦	** (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	-	-
♦	NA	♦	NA	♦	NA	♦	-	-
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)
♦	NA	♦	NA	♦	NA	♦	-	** (Vehicle open – Alarm disarms)

♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦		♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk and rear right door open)*
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk and rear right door open)*
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk and rear right door open)*
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk and rear right door open)*
♦	--	♦	--	♦	--	--	--	-- (Trunk and rear right door open)*
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	NA	NA	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
--	--	--	--	--	--	--	--	--
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	NA	♦	NA	♦	NA	♦	♦	-- (Trunk unlock)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (Vehicle has to be already unlocked)
♦	♦	♦	♦	♦	♦	♦	♦	-- (Vehicle has to be already unlocked)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP/RKE Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦	♦	♦	♦	♦	♦	♦	♦	-- (Trunk unlock)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)
♦	♦	♦	♦	♦	♦	♦	♦	-- (by TSP Vehicle open – Alarm disarms)

♦									(by TSP Vehicle open – Alarm disarms)
♦									(by TSP Vehicle open – Alarm disarms)
♦									(by TSP Vehicle open – Alarm disarms)
♦								NA	
♦								NA	
♦								(Trunk unlock)	
♦								(by TSP Vehicle open – Alarm disarms)	
♦								(by TSP Vehicle open – Alarm disarms)	
♦								(by TSP Vehicle open – Alarm disarms)	
♦								(by TSP Vehicle open – Alarm disarms)	
♦								(by TSP Vehicle open – Alarm disarms)	
♦								(Trunk unlock)	
♦								(by TSP/RKE Vehicle open – Alarm disarr	
♦								(by TSP/RKE Vehicle open – Alarm disarr	
♦								(by TSP/RKE Vehicle open – Alarm disarr	
♦								(by TSP/RKE Vehicle open – Alarm disarr	
♦								(by TSP/RKE Vehicle open – Alarm disarr	
♦								(Trunk unlock)	
♦								(Trunk unlock)	
♦								(Vehicle has to be already unlocked)	
♦	NA	♦	NA	♦	NA	♦	--	(Vehicle open – Alarm disarms)	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	(Vehicle open – Alarm disarms)	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	NA	♦	NA	♦	NA	♦	--	NA	
♦	♦	♦	♦	♦	♦	♦	--	(Vehicle open – Alarm disarms)	
♦	♦	♦	♦	♦	♦	♦	--	(Vehicle open – Alarm disarms)	

◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)
◆	◆	◆	◆	◆	◆	◆	◆	(by TSP Vehicle open – Alarm disarms)

◆	NA	--	NA	◆	NA	◆	◆	-- (Trunk unlock)*
◆	NA	--	NA	◆	NA	◆	◆	-- (Trunk unlock)*
◆	NA	--	NA	◆	NA	◆	◆	-- (Trunk unlock)*

◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA

◆	◆	◆	◆	◆	◆	NA	NA	-- * (Trunk unlock)
◆	◆	◆	◆	◆	◆	NA	NA	-- * (Trunk unlock)
◆	◆	◆	◆	◆	◆	NA	NA	-- * (Trunk unlock)
◆	◆	◆	◆	◆	◆	NA	NA	-- * (Trunk unlock)

◆	NA	◆	NA	◆	NA	NA	NA	-- * (Trunk unlock)
---	----	---	----	---	----	----	----	---------------------

◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	◆	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
◆	NA	--	NA	◆	NA	◆	--	NA
--	--	--	--	--	--	--	--	--

◆	◆	◆	--	◆	◆	◆	◆	-- (Trunk unlock)
◆	◆	◆	--	◆	◆	◆	◆	-- (Trunk unlock)
◆	◆	◆	--	◆	◆	◆	◆	-- (Trunk unlock)

◆	◆	◆	NA	◆	◆	◆	◆	.. (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	◆	.. (Trunk unlock)
◆	NA	—	NA	◆	NA	◆	—	—
◆	◆	—	NA	◆	◆	◆	—	** (TSP – Trunk unlock)
◆	◆	—	—	◆	◆	◆	—	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	(Trunk Open)
◆	◆	◆	◆	◆	◆	—	—	(Trunk Open)
◆	◆	◆	◆	◆	◆	◆	◆	** (TSP – Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	..
◆	◆	◆	◆	◆	◆	—	—	..
—	—	—	—	—	—	—	—	—
◆	NA	◆	NA	◆	NA	?	?	.. (Trunk unlock)
◆	◆	◆	◆	◆	◆	—	—	..
◆	◆	◆	◆	◆	◆	◆	◆	◆*
◆	◆	◆	◆	◆	◆	◆	◆	◆*
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock – Alarm disarms)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock – Alarm disarms)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock – Alarm disarms)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)
◆	NA	◆	NA	◆	NA	◆	◆	** (Trunk unlock)

◆	—	◆	—	◆	—	◆	◆	(Trunk ad rear doors open – Alarm disa
◆	—	◆	—	◆	—	◆	◆	(Trunk ad rear doors open – Alarm disa

◆	◆	◆	—	◆	◆	◆	◆	Rear vehicle unlocking*
◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	—	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	—	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock
◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock

◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)
◆	◆	◆	NA	◆	◆	◆	—	"" (Trunk unlock)

◆	◆	◆	◆	◆	◆	◆	◆	Trunk unlock
---	---	---	---	---	---	---	---	--------------

◆	NA	—	NA	◆	NA	◆	◆	-
◆	NA	—	NA	◆	NA	◆	◆	-

◆	NA	◆	NA	◆	NA	—	—	"" (Trunk unlock)
---	----	---	----	---	----	---	---	-------------------

◆	◆	◆	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	---	----	---	---	---	---	-------------------

◆	◆	◆	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	---	----	---	---	---	---	-------------------

◆	◆	◆	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	---	----	---	---	---	---	-------------------

◆	◆	◆	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	---	----	---	---	---	---	-------------------

◆	◆	◆	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	---	----	---	---	---	---	-------------------

◆	◆	--	NA	◆	◆	◆	◆	"" (Trunk unlock)
---	---	----	----	---	---	---	---	-------------------

-- -- -- -- -- -- -- -- --
-- -- -- -- -- -- -- -- --
-- -- -- -- -- -- -- -- --
-- -- -- -- -- -- -- -- --
-- -- -- -- -- -- -- -- --
-- -- -- -- -- -- -- -- --

♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*
♦ ♦ ♦ NA ♦ ♦ -- -- --*

♦ -- ♦ -- ♦ -- -- -- --*
♦ -- ♦ -- ♦ -- -- -- --*
♦ -- ♦ -- ♦ -- -- -- --*
♦ -- ♦ -- ♦ -- -- -- --*
♦ -- ♦ -- ♦ -- -- -- --*

♦ ♦ ♦ ♦ ♦ ♦ -- -- --*
♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*
♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*

♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*

♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*
♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*
♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ --*

♦ ? ♦ ? ♦ ? -- -- --*
♦ ? ♦ ? ♦ ? -- -- --*
♦ ♦ ♦ ? ♦ ♦ -- -- Trunk unlock

♦ ♦ ♦ ♦ ♦ ♦ -- -- --*
♦ ♦ ♦ ♦ ♦ ♦ -- -- --*
♦ ♦ ♦ ♦ ♦ ♦ -- -- --*
♦ ♦ ♦ ♦ ♦ ♦ -- -- --*

* Alarm disarm if the vehicle lights up indicator lights when trunk is opened by RKE

**Repeated locking isn't available in vehicle equipped only with RKE

**Repeated locking isn't available in vehicle equipped only with RKE

**Repeated locking isn't available in vehicle equipped only with RKE

* Alarm disables trunk-US-Shock

* Alarm disables trunk-US-Shock

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Alarm stay armed but the triggers for trunk, shock or US are permanently disabled, because the trunk or rear right door remain permanently unlocked

* Trunk saw as trigger OEM alarm

* Trunk saw as trigger OEM alarm ** Unlocking Tsp seen only for front left door

RELAY

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

PULSE

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

RELAY

PULSE

PULSE

PULSE

PULSE

RELAY

RELAY

* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons

en)
en)
en)

)

RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY

PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY

RELAY	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY

RELAY	RELAY
RELAY	RELAY
RELAY	RELAY

RELAY	RELAY
RELAY	RELAY
RELAY	RELAY

CAN	RELAY
CAN	RELAY

PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY

CAN	RELAY
CAN	RELAY

* The vehicle allow the Trunk unlocking by RKE just when the vehicle is unlock

- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock
- * Vehicle seen has RKE two button only, and trunk unlock with TSP lead to a vehicle unlock

* Trunk unlock with TSP or trunk unlock for RKE with 3 buttons

RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY

RELAY	RELAY
RELAY	RELAY

RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY
RELAY	RELAY

PULSE	RELAY
-------	-------

PULSE	RELAY
-------	-------

CAN (only side and rear indicator)	RELAY
CAN (only side and rear indicator)	RELAY
CAN (only side and rear indicator)	RELAY
CAN (only side and rear indicator)	RELAY
CAN (only side and front indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (only side indicator)	RELAY
CAN (only side and rear indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY
CAN (only side indicator)	RELAY

CAN	CAN
CAN	CAN
CAN	CAN

opening)

* Alarm arms while a door is opened - ** Alarm disarm for trunk unlock (trunk and sliding door still remains unlocking)

CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN

CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY
CAN	RELAY

CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY

CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY

CAN	RELAY
-----	-------

CAN (all lamp indicators)	RELAY
---------------------------	-------

Mechanical/electrical closing of the rear doors/trunk doesn't lock them, after RKE unlocks you have to follow a full locking
Mechanical/electrical closing of the rear doors/trunk doesn't lock them, after RKE unlocks you have to follow a full locking
Mechanical/electrical closing of the rear doors/trunk doesn't lock them, after RKE unlocks you have to follow a full locking

trunk position
trunk position
trunk position
potential unlocking (only driver door or trunk)

trunk position

* After unlocked the trunk by RKE (alarm disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it was keep unlocked

CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
CAN (all lamp indicators)	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE (From List 33)	RELAY
PULSE (From List 33)	RELAY
PULSE (From List 33)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE (From List 29)	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE (From List 29)	RELAY

* Vehicle with TSP only
* Vehicle with TSP only

Alarm disarms when Trunk is unlocked by TSP, instead stay armed when is unlocked by remote
Alarm disarms when Trunk is unlocked by TSP, instead stay armed when is unlocked by remote

Alarm disarms when Trunk is unlocked by TSP, instead stay armed when is unlocked by remote

* Alarm trigs when is unlocked by remote
* Alarm trigs when is unlocked by remote

* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op

* After unlocked the trunk by RKE (alarm disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it will keep open
* After unlocked the trunk by RKE (alarm disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it will keep open
* After unlocked the trunk by RKE (alarm disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it will keep open

* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op
* After unlocked the trunk by RKE (alarm not disarms) and open it physically – to re-lock the trunk pressing RKE vehicle lock button (alarm not repeats lock command) otherwise it will keep op

CAN (side lamps) + RELAY (Rear lamps) RELAY
CAN (side lamps) + RELAY (Rear lamps) RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY
PULSE RELAY
RELAY RELAY

RELAY RELAY
RELAY RELAY

CAN RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY

RELAY RELAY

RELAY RELAY

RELAY RELAY
RELAY RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY

* After unlocked the trunk by RKE (alarm disarms) – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it will keep open
* After unlocked the trunk by RKE (alarm disarms) – to re-lock the trunk pressing RKE vehicle lock button (alarm re-arms) otherwise it will keep open

* The third button of RKE unlock the rear doors – Alarm in this case disarms

* The third button of RKE unlock the trunk – Alarm disarms and rearms when trunk is physically closed

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

RELAY RELAY
RELAY RELAY

PULSE RELAY
PULSE RELAY
PULSE RELAY
PULSE RELAY
PULSE RELAY
PULSE RELAY
PULSE RELAY
PULSE RELAY

RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY
RELAY RELAY

RELAY RELAY

RELAY RELAY
RELAY RELAY

RELAY RELAY

PULSE RELAY

CAN (Parking light) CAN (OEM ALARM HORN)

PULSE RELAY
PULSE RELAY

CAN (Parking light) CAN (OEM ALARM HORN)

RELAY RELAY

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

Mechanical key doesn't disarm alarm after 30 seconds locking vehicle by RKE or TSP

RELAY

RELAY

CAN (Parking light)

CAN (OEM ALARM HORN)

CAN (Parking light)

CAN (OEM ALARM HORN)

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

RELAY

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

PULSE

CAN

* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"

* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"
* Enable dashboard vehicle funtion "unlock all doors with trunk unlocking"

Unlock
Unlock

PULSE	CAN
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY

PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN

PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN
PULSE	CAN

PULSE	CAN
-------	-----

PULSE	WIRE
-------	------

PULSE	RELAY
PULSE	RELAY

RELAY	RELAY
-------	-------

PULSE	RELAY
PULSE	RELAY

PULSE	RELAY
PULSE	RELAY

RELAY	RELAY
-------	-------

* Connection to Engine Can-Bus
* Connection to Engine Can-Bus
* Connection to Engine Can-Bus
* Connection to Engine Can-Bus
* Connection to Engine Can-Bus
* Connection to Engine Can-Bus

*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility

*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility
*RKE w/o trunk button facility

*RKE unlocks the trunk just if it is locked otherwise locks the vehicle

*RKE w/o trunk button facility – with TSP button on the trunk, it unlocks/locks the vehicle
*RKE w/o trunk button facility – with TSP button on the trunk, it unlocks/locks the vehicle
*RKE with trunk button facility – with TSP button on the trunk, it unlocks/locks the vehicle

*RKE with trunk button facility – with TSP button on the trunk, it unlocks just the trunk

* Trunk unlock and physically open itself

*RKE with trunk button facility – with TSP button on the trunk, it unlocks just the trunk
*RKE with trunk button facility – with TSP button on the trunk, it unlocks just the trunk
*RKE with trunk button facility – with TSP button on the trunk, it unlocks just the trunk

*RKE w/o trunk button facility
*RKE w/o trunk button facility

* Trunk unlock and physically open itself
* Trunk unlock and physically open itself
* Trunk unlock and physically open itself
* Trunk unlock and physically open itself

RELAY
RELAY
RELAY
RELAY
RELAY
RELAY

CAN
CAN
CAN
CAN
CAN
CAN
CAN

RELAY
RELAY
RELAY
RELAY
RELAY

PULSE
PULSE
PULSE
PULSE

PULSE

RELAY

PULSE
PULSE
PULSE

PULSE
PULSE
PULSE

PULSE
PULSE
PULSE
PULSE

* Trunk unlock and physically open itself
* Trunk unlock and physically open itself

*RKE unlock just the trunk – TSP button unlock all vehicle

* Connection to Engine Can-Bus
* Connection to Engine Can-Bus
* Connection to Engine Can-Bus

* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons
* Trunk unlock for RKE with 3 buttons

* Trunk unlock for RKE with 3 buttons or TSP

* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP

* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP
* Trunk unlock for RKE with 3 buttons or TSP

PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
--	--
--	--
--	--
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY
PULSE	RELAY

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE CAN
WIRE CAN
WIRE CAN
WIRE CAN
WIRE CAN

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

CAN WIRE
CAN WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE	CAN
WIRE	CAN
WIRE	CAN

CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN
CAN	CAN

WIRE	WIRE
------	------

WIRE	CAN
------	-----

WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN

CAN	CAN
CAN	CAN
CAN	CAN

WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN
WIRE	CAN

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE	WIRE
------	------

WIRE	WIRE
------	------

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE	WIRE
------	------

WIRE	WIRE
------	------

WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE
WIRE	WIRE

WIRE CAN
WIRE CAN

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
-- --
-- --
-- --
-- --

WIRE WIRE
-- --
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?
WIRE CAN?

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE CAN

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE

WIRE WIRE

-- --
-- --
-- --

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE
WIRE WIRE
WIRE WIRE
WIRE WIRE

WIRE WIRE

WIRE WIRE

